

Quantum Unity CPUs
140 CPU 311 10,
140 CPU 434 12A,
140 CPU 534 14A, and
140 CPU 534 14B


June 2009 eng

Table of Contents



	Safety Information	5
	About the Book	7
Chapter 1	Quantum Unity CPUs	9
	At a Glance	9
	Specifications	10
	Front Panel Topology	14
	Rear Panel Topology	21
	Option Module Interface Support	22
	Index	27

Safety Information



Important Information

NOTICE

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a Danger or Warning safety label indicates that an electrical hazard exists, which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



DANGER

DANGER indicates an imminently hazardous situation, which, if not avoided, **will result** in death, serious injury, or equipment damage.



WARNING

WARNING indicates a potentially hazardous situation, which, if not avoided, **can result** in death, serious injury, or equipment damage.



CAUTION


CAUTION indicates a potentially hazardous situation, which, if not avoided, **can result** in injury or equipment damage.

PLEASE NOTE

Electrical equipment should be serviced only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material. This document is not intended as an instruction manual for untrained persons.

© 2003 Schneider Electric All Rights Reserved.

About the Book



At a Glance

Document Scope This instruction sheet provides information on the Quantum Unity CPUs: 140 CPU 311 00, 140 CPU 434 12A, 140 CPU 534 14A, and 140 CPU 534 14B.

Validity Note The data and illustrations found in this book are not binding. We reserve the right to modify our products in line with our policy of continuous product development. The information in this document is subject to change without notice and should not be construed as a commitment by Schneider Electric.

This document applies to the installation and use of ProWORX 32 in Windows 98, Windows Me, Windows XP, Windows NT 4.0, and Windows 2000 environments and ProWORX Server in Windows XP, Windows NT 4.0, and Windows 2000 environments.

Related Documents

Title of Documentation	Reference Number
Modicon Quantum Automation Series Hardware Reference Guide	840 USE 100 00
Quantum with Unity Pro Hardware Reference Manual	UNYUSE10010V11X

Product Related Warnings

Schneider Electric assumes no responsibility for any errors that may appear in this document. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

No part of this document may be reproduced in any form or by any means, electronic or mechanical, including photocopying, without express written permission of Schneider Electric. All rights reserved. Copyright 2003.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When controllers are used for applications with technical safety requirements, please follow the relevant instructions.

Failure to use Schneider Electric software or approved software with our hardware products may result in improper operating results.

Failure to observe this product related warning can result in injury or equipment damage

User Comments

We welcome your comments about this document. You can reach us by e-mail at techpub@schneider-electric.com

Quantum Unity CPUs



At a Glance

Overview


This chapter provides information on the specifications and topology of the Quantum Unity CPUs 140 CPU 311 10, 140 CPU 434 12A, 140 CPU 534 14A, and 140 CPU 534 14B. In addition, information is provided on network modules that are supported by these Quantum Unity CPUs.

What's in this Chapter?

This chapter contains the following topics:

Topic	Page
Specifications	10
Front Panel Topology	14
Rear Panel Topology	21
Option Module Interface Support	22

The following illustration shows the 140 CPU 434 12A module and its components. The 140 CPU 534 14A and 140 CPU 534 14B modules have the same components.



Specifications The following table shows the specifications for the 140 CPU 311 10, 140 CPU 434 12A, 140 CPU 534 14A, and 140 CPU 534 14B modules.

Specifications				
Model	140CPU31110	140CPU43412A	140CPU53414A	140CPU53414B
Processor	80486	80486	80586	80486
Math Coprocessor	Yes	Yes	Yes	Yes
Clock Speed	66 MHz	66 MHz	133 MHz	100 MHz
User Logic/Reference Capacity				
Maximum IEC program (Concept/ProWorx)	N/A	846 k	2.5 M	2.5 M
IEC Application without PCMCIA (Unity)				
Program and unlocated data (min)	400 k	800k	2.7 m	2.7 m
Located data and config (max)	148 k	256 k	256 k	256 k
984 Ladder Logic (not in Unity)	N/A	64 k	64 k	64 k
Discrete	51.7 k	64 k	64 k	64 k
Register				
Unity	10 k	64 k	64 k	64 k
Concept/ProWORX	N/A	57 k	57 k	57 k
Local I/O				
Maximum I/O Words				
Unity	64 in and 64 out/module			
Concept/ProWORX	64 in and 64 out/drop			
Maximum Number of I/O Racks	2 (requires expander)			
Remote I/O				
Maximum I/O Words per Drop	64 in and 64 out			
Maximum Number of Remote Drops	31			
Number of Networks	1			
Distributed I/O				
Maximum Networks per System	3			
Maximum Words per Network	500 in and 500 out			
Maximum Words per Node	30 in and 32 out			
Maximum Number of Network Module Interfaces	2	6	6	6
Watchdog Timer	250 ms (software adjustable)			
Logic Solve Time	0.1 ... 0.5 ms/k	0.1 ... 0.5 ms/k	0.9 ... 0.45 ms/k	0.9 ... 0.45 ms/k

Specifications				
Model	140CPU31110	140CPU43412A	140CPU53414A	140CPU53414B
Battery				
Type	3 V Lithium	3 V Lithium	3 V Lithium	3 V Lithium
Service Life	1200 mAH	1200 mAH	1200 mAH	1200 mAH
Shelf Life	10 years	10 years	10 years	10 years
Load Current, Typical	7 mA	7 mA	14 mA	14 mA
Load Current, Max	210 mA	210 mA	210 mA	210 mA
Communication Ports				
Modbus (RS-232)	2	2	2	2
Modbus Plus	1	1	1	1
Programming Software Capability	Unity, version 1.0 minimum	Modsoft, version 2.6 or higher Concept, version 2.1 or higher ProWORX NxT, version 2.0 or higher ProWORX Plus, version 1.05 or higher ProWORX 32, version 1.0 or higher Unity, version 1.0 or higher		
Bus Current Required	1250 mA	1250 mA	1250 mA	1250 mA
Key Switch	No	Yes	Yes	Yes
TOD Clock Accuracy	+/- 8.0 seconds/day 0 ... 60° C			
Operating Temperature	0 ... 60° C			
¹ CPUs 140 CPU 434 12 A/140 CPU 434 14A are shipped with Concept/ProWORX operating systems (exec) preloaded. If you need Unity support, you need to load the Unity exec, available on the Web, into the CPU.				

Front Panel Topology

Overview


The following provides information on the front panel topology of the Quantum CPU modules. There are two switches (a three-position slide switch and a three-position key switch) located on the front of the 140 CPU 434 12A, 140 CPU 534 14A, and 140 CPU 534 14B modules. The 140 CPU 311 10 module has two slide switches but does not have a key switch.

Front Panel Slide Switches

The 140 CPU 311 10 module has two, three-position slide switches. The left switch is used for memory protection when in the top position and no memory protection in the bottom position. The three-position slide switch on the right is used to select the communication parameter settings for the Modbus ports.

The 140 CPU 434 12A, 140 CPU 534 14A, and 140 CPU 534 14B modules have a single slide switch that is used to select the comm parameter settings for the Modbus (RS-232) ports.

The following illustration shows the slide switches for these two modules. The 140 CPU 311 10 uses both slide switches. The 140 CPU 434 12A, 140 CPU 534 14A, and 140 CPU 534 14B modules use only the slide switch on the right.



Note: The CPU hardware defaults to bridge mode when the front panel switch is set to RTU or ASCII mode. When networking controllers, a panel device connected to the CPU Modbus port can communicate with the controller to which it is connected, as well as log into any nodes on the Modbus Plus network.

Setting the slide switch to the top position assigns ASCII functionality to the port; the following communication parameters are set and cannot be changed.

ASCII Comm Port Parameters	
Baud	2,400
Parity	Even
Data Bits	7
Stop Bits	1
Device Address	Rear panel rotary switch setting


Setting the slide switch to the middle position assigns remote terminal unit (RTU) functionality to the port; the following comm parameters are set and cannot be changed.

RTU Comm Port Parameters	
Baud	9,600
Parity	Even
Data Bits	8
Stop Bits	1
Device Address	Rear panel rotary switch settings

Setting the slide switch to the bottom position gives you the ability to assign comm parameters to the port in software; the following parameters are valid.

Valid Com Port Parameters	
Baud	50 ... 19,200
Data Bits	7/8
Stop Bits	1/2
Parity	Enable/Disable Odd/Even
Device Address	1 ... 247

The key switch is used to protect memory from programming changes while the controller is in operation. The following illustration shows the key switch that is used with the 140CPU43412A, 140 CPU 534 14A, and 140 CPU 534 14B modules.



Note: The key switch positions shown next to the switch (above) are for reference only and are marked on the module as indicated on the right.



Note: The 140 CPU 434 12A, 140 CPU 534 14A, and 140 CPU 534 14B processors feature the key switch illustrated above, while the 140 CPU 311 10 has a slide switch.

The following table provides key/slider switch information for all three low end CPUs.

CPU Type	Switch Position	Behavior	Protected?	Accepts Stop or Start?	Key Switch Transition
Quantum 140 CPU 311 10	Mem Prt On	The application in Flash memory is not transferred to internal RAM; a warm restart of the application is triggered.	Y	N	From Mem Prt Off: does not modify last controller state and rejects programmer changes.
	Not used	Do not use this position, because it may lead to undefined operation	Y	N	n/a
	Mem Prt Off	The application in Flash memory is automatically transferred to internal RAM when the PLC is powered up. A cold restart of the application is triggered.	N	Y	From Mem Prt On : enables programmer changes and starts controller if stopped.
Quantum 140 CPU 434 12A 140 CPU 534 14A	Stop	The application in Flash memory is not transferred to internal RAM; a warm restart of the application is triggered.	Y	N	From Start or Mem Prt: stops controller, if running, and voids programmer changes.
	Mem Prt	The application in Flash memory is not transferred to internal RAM. A warm restart of the application is triggered.	Y	N	From Stop or Start: prevents program changes, controller run status is unchanged.
	Start	The application in Flash memory is automatically transferred to internal RAM when the PLC is powered up. A cold restart of the application is triggered.	N	Y	From Stop: enables programmer changes, starts controller. From Mem Prt: accepts programmer changes, starts controller if stopped.

Front Panel Modbus Connector

The Quantum 140 CPU 434 12A, 140 CPU 534 14A, and 140 CPU 534 14B are equipped with two nine-pin RS-232 connectors that support Modicon's proprietary Modbus communication protocol. The 140 CPU 311 10 module has one nine-pin RS-232 connector. The following is the Modbus port pinout connections for nine-pin connections.



The following abbreviations are used in the figures above.

TX: Transmitted Data	DTR: Data Terminal Ready
RX: Received Data	CLS: Clear to Send
RTS: Request to Send	NC: No Connections
DSR: Data Set Ready	CD: Carrier Detect
GND: Ground	

Note: Although the Modbus ports electrically support existing Modbus cables, it is recommended that a Modbus programming cable (Part # 990NAA26320) be used. This cable has been designed to fit under the door of a Quantum CPU or NOM module.

**LED Indicators
and Descriptions**

The following illustration shows the LED indicators for the 140CPU31110, 140CPU43412A, 140 CPU 534 14A, and 140 CPU 534 14B modules.




Table with three columns.

LEDs	Color	Indication When On
Ready	Green	The CPU has passed power-up diagnostics
Run	Green	The CPU has been started and is solving logic.
Bat Low	Red	The battery needs replacing or is not present.
Modbus	Green	Communications are active on the Modbus port 1 or 2.
Modbus +	Green	Communications are active on the Modbus Plus port.
Error A	Red	Indicates communications error on the Modbus Plus port.
Mem Prt	Amber	Memory is write-protected (the memory protect switch is on).

LED Error Codes Table with three columns.

LED Error Codes		
Number of Blinks	Code	Error
Continuous	0000	requested kernel mode
2	80B	ram error during sizing
	80C	run output active failed
	82E	MB command handler stack error
3	769	bus grant received
	72A	not master asic on cpu
	72B	master config write bad
	72C	quantum bus DPM write failure
	72F	plc asic loopback test
	730	plc asic BAD_DATA
	4	604
605		bad UPI response opcode
606		UPI bus diagnostic error
607		modbus cmd-buffer overflow
608		modbus cmd-length is zero
609		modbus abort command error
614		mbp bus interface error
615		bad mbp response opcode
616		timeout waiting for mbp
617		mbp out of synchronization
618		mbp invalid path
619		page 0 not paragraph aligned
61E		bad external uart hardware
61F		bad receive comm state
620		bad receive comm state
I621		bad transmit comm state
I622		bad comm state trn_asc
623		bad comm state trn_rtu
624		bad comm state rcv_rtu
I625	bad comm state rcv_asc	
626	bad modbus state tmr0_evt	
627	bad modbus state trn-int	

LED Error Codes		
Number of Blinks	Code	Error
	628	bad modbus state rcv-int
	631	bad interrupt
5	503	ram address test error
	52D	P.O.S.T. BAD MPU ERROR
6	402	ram data test error
7	300	EXEC not loaded
	301	EXEC checksum
8	8001	Kernal prom checksum error
	8002	flash prog/erase error
	8003	unexpected executive return

Rear Panel Topology

Overview

The address switch, which is comprised of two rotary switches, is located on the rear panel of the Quantum CPUs. The address switch is used for setting Modbus Plus node and Modbus port addresses.

Note: The highest address that may be set with the address switch is 64.

SW1 (the top switch) sets the upper digit (tens) of the address, SW2 (the bottom switch) sets the lower digit (ones) of the address. The illustration below shows the correct setting for an example address of 11.




Table with three columns.

SW1 and SW2 Address Settings		
Node Address	SW1	SW2
1 ... 9	0	1 ... 9
10 ... 19	1	0 ... 9
20 ... 29	2	0 ... 9
30 ... 39	3	0 ... 9
40 ... 49	4	0 ... 9
50 ... 59	5	0 ... 9
60 ... 64	6	0 ... 4

Note: If "0" or an address greater than 64 is selected, the Modbus + LED will be "ON" steady to indicate the selection of an invalid address.

Option Module Interface Support

Overview

The 140 CPU 434 12A, 140 CPU 534 14A, and 140 CPU 534 14B each support up to six network modules (i.e., Modbus Plus, Ethernet, and Multi-Axis Motion option modules) using the option module interface technique. However, only two Modbus Plus modules can have full functionality, including Quantum DIO support. The 140 CPU 311 10 supports up to two network modules.

Quantum Communications and Network Modules

The following table shows the network modules that are supported.

Model Number	Description	Module Interface Technique	Loadable Required (not in Unity)	Backplane Support			Bus Power mA
				Local	RIO	DIO	
140CRP81100	Profibus	Direct CPU Driver	N	Y	N	N	1200
140CRP93100	Remote I/O Head interface, single cable	Direct CPU Driver	N	Y	N	N	780
140CRP93200	Remote I/O Head Interface, dual cable	Direct CPU Driver	N	Y	N	N	780
140CHS21000 (not in Unity)	Hot Standby Processor Kit	Direct CPU Driver	Y	Y	N	N	700
140NOA61110 (not in Unity)	Interbus Master (G3)	Direct CPU Driver	Y	Y	N	N	700
140NOA62200	Interbus Master (G4)	Direct CPU Driver	Y	Y	N	N	700
140NOM21100	Modbus Plus Options, single cable	Option module	N	Y	N	N	780
140NOM21200	Modbus Plus Option, dual cable	Option module	N	Y	N	N	780
140NOM25200	Modbus Plus Option, single channel fiber	Option module	N	Y	N	N	900
140NOE31100	Ethernet SY/MAX Twisted Pair	Option module	N	Y	N	N	1000

Model Number	Description	Module Interface Technique	Loadable Required (not in Unity)	Backplane Support			Bus Power mA
				Local	RIO	DIO	
140NOE35100	Ethernet SY/MAX Fiber Optic	Option Module	N	Y	N	N	1000
140NOE77101	Ethernet	Option Module	N	Y	N	N	1000
140NOE77111	Ethernet Web Server	Option Module	N	Y	N	N	1000
140MMS42500	Multi-Axis Motion Controller w/ SERCOS	Option Module	N	Y	N	N	2500
140NOL91110 (not in Unity)	LonWorks Interface, twisted pair TPT/XF-78	I/O Map (16/16)	Y	Y	Y	N	950

**Quantum
Modbus and
Modbus Plus
Services**

This table describes the types of services provided by Modbus and Modbus Plus.

Type	Service Description	Native CPU Ports		NOM 1-2 Ports		NOM 3-6 Ports ¹	
		Modbus	Modbus Plus	Modbus	Modbus Plus	Modbus	Modbus Plus
Modbus Services	Default Modbus Port Parameters	Y	-	Y	-	Y	-
	Configurable Modbus Port Parameters	Y	-	Y	-	Y ⁵	-
	Modbus to Modbus Plus Bridging	Y ²	-	Y ³	-	Y ³	-
	Local CPU Programming	Y ⁴	-	Y ⁴	-	N	-
	Remote CPU Programming over Modbus Plus	Y ⁴	-	Y ⁴	-	Y ²	-
	Modbus access to local CPU	Y	-	Y	-	N	
	Modbus access to remote CPU over Modbus Plus	Y	-	Y	-	Y	-
	Modbus Network Slave Support	Y	-	N	-	N	-
	Modbus Master support with XMIT Loadable	Y	-	N	-	N	-
Executive Firmware Loading Support	Y	-	N	-	N	-	

Type	Service Description	Native CPU Ports		NOM 1-2 Ports		NOM 3-6 Ports ¹	
		Modbus	Modbus Plus	Modbus	Modbus Plus	Modbus	Modbus Plus
Modbus Plus Services	MSTR read/write register messaging ⁶	-	Y	-	Y	-	Y
	MSTR read/write Global Data messaging	-	Y	-	Y	-	Y
	MSTR get/clear local/remote statistics	-	Y	-	Y	-	Y
	Config Extension Global Data Support	-	Y	-	Y	-	N
	Config Extension Peer Cop Support	-	Y	-	Y	-	N
	Distributed I/O Support	-	Y	-	Y	-	N
	CPU Programming	-	Y ⁴	-	Y ⁴	-	Y ⁴
	Executive Firmware Loading Support	-	Y	-	N	-	Y

1. Only supported on the 140 CPU 434 12A and 140 CPU 534 14A Quantum controllers.
2. The native CPU Modbus port can be disabled from bridge mode operation with the native Modbus Plus port.
3. Modbus ports on NOMs are always in bridge mode with their associated Modbus Plus port.
4. Only one programmer connection can be logged in at a time to any CPU, and only one program monitor can be attached at a time to any CPU.
5. Modbus port parameters on NOMs 3-6 are defined by Modbus Port 3 in Concept and Modsoft when the comm parameter selector switch is in mem.
6. Up to 4 MSTR read/write register instructions can be serviced per CPU scan per Modbus Plus port.

