


1. Overview




- (1)Front panel (2)LED indicator (3)Junction box (4)Support frame (5)DC switch
- (6)PV terminal (7)Vent valve (8)USB port (9)COM port (10)Anti-collision angle
- (11)Waterproof silicone pad (12)AC terminal block (13)Grounding copper bar


⚠ Note:
 1. This document is for quick installation guidance only, please refer to User Manual for more details.
 2. Growatt shall not be liable for any damage resulting from unproper installation.

2. Installation


System overview



2.1 Installation requirements




2.2 Wall mounting



⚠ Note:
 Please choose a wall with a thickness of more than 100mm, and use a φ10 drill bit to drill a hole with a depth of 60mm in the wall mount installation space.
 unit: mm

2.3 Communication module installation




3. Electrical connection

Please prepare the cable before connecting as follows.


No.	Cable name	Type	Recommend model (Copper wire)	Recommend model (AL. wire)
1	Protective grounding wire	Single multi-core yellow-green wire	50mm ²	70mm ²
2	AC output wire	Single multi-core wire	70mm ² - 240mm ²	95mm ² - 300mm ²
3	PV input wire	Single multi-core wire	4mm ² - 6mm ²	/
4	Communication wire	RS485	/	/

⚠ Note:
 1. Please make sure all switches are in "OFF" position before wiring. For personal safety, please do not operate with electricity.
 2. If the diameter of the cable does not match the terminal, or the cable is aluminum wire, please contact our after-sales personnel.

3.1 Grounding




3.2 AC output connection




3.3 DC connection

3.3.1 PV input terminal installation



3.3.2 Plug in PV terminal




3.3.3 Communication cable installation

3.3.3.1 RS485 installation


No.	Description	No.	Description
1/2	485-1 Shield	9	DRMs signal
3	485-1 A1	10	
4	485-1 B1	11	
5	485-1 A2	12	
6	485-1 B2	13	
7	485-2 A1	14	
8	485-2 B1	15/16	

Note: When multi-parallel inverter are installed, matching resistors need to be introduced.

3.3.3.2 USB installation



3.3.3.3 Multi-parallel inverter installation



4. Post-installation check

No.	Acceptance criteria	No.	Acceptance criteria
1	The inverter is installed correctly, firmly and reliably.	6	The RS485 communication cable is installed correctly and firmly.
2	The ground wire connected well and the connection is firm and reliable.	7	The cable tie port is trimmed well without leaving sharp corners, meets the requirements of the user.
3	All switches are in the OFF state.	8	All exposed terminals are well protected and there are no vacant ports.
4	All wiring is correct and securely connected.	9	Pay attention to clean up all construction residues.
5	The wiring of the cable is reasonable, meets the requirements, and there is no phenomenon of broken skin.		


5. Power on and off steps

Note:
 Before powering on, please make sure that all voltage ranges are within the working range of the machine, otherwise the machine may be damaged.
 Follow the steps below to switch on and off:
 1. Close the switch between the PV and the inverter.
 2. Close the switch between the power grid and the inverter.
 3. If you need to set the inverter, please refer to the inverter user manual for details.
 4. The shutdown steps are opposite to the above order.

6. Status of PV grid inverter

Customer can read more information by LED. Follow are the instruction of LED:

Indicator	Function	State	Instructions
A	PV voltage indicator	Green light is always on	PV voltage $\geq 400V$
B	AC voltage indicator	Green light is always on	Inverter is in the grid state
		Green light is flashing	Inverter grid-connected countdown/fault status
C	Alarm / fault indicator	Red light is flashing slowly	Inverter warning
		Red light is always on	Inverter fault
D	Communication indicator	Green light is always on	The inverter communicate normally
E	Power indicator	Green light is always on	The eight LEDs represent the power of the inverter
	Fault code indicator	Green light is always on	For the detail fault code, please refer to the manual



7. Service and contact

Shenzhen Growatt New Energy CO.,LTD
 4-13/F, Building A, Sino-German(Europe) Industrial Park,
 Hangcheng Ave, Guxing Community, Xixiang Subdistrict,
 Bao'an District, Shenzhen, China

T +86 0755 2747 1942
 E service@ginverter.com
 W www.ginverter.com



Download Manual



Growatt New Energy