## Battery Tester With Color LCD Display MDXT-600 User Manual



Thank you for purchasing our battery tester , please read this manual carefully and save it for reference before using !

**MDXT-600** battery tester is our newest version with color LCD Display. And it has a feature of review the latest 20 groups data. With the world's most advanced conductance testing technology, it can easily, quickly and accurately measure the actual cold cranking amps capability of the vehicle starting battery, healthy state of the battery, which can achieve quick vehicle repair.

### **Product specification:**

- 1. Application: 12V batteries and 12V&24V car system test
- 2. Measure Range:

Measure Standard	Measure Range	
CCA	40-2000	
BCI	40-2000	
CA	40-2000	
MCA	40-2000	
JIS	26A17245H52	
DIN	40-1400	
IEC	40-1400	
EN	40-2000	
SAE	40-2000	
GB	3-220Ah	

- 3. Working Environment Temp:-18°C-50°C
- 4. Special test clip: Double conductor Kelvin clamp
- 5. Housing Material: Acid-resistant ABS plastic
- 6. Measure Range: 3-220Ah
- 7. Voltage Measure Range: 7-30VDC

## Main functions:



According to the tester, you can press UP/DOWN key to choose:

- $(\ensuremath{\underline{1}})$  Out of Vehicle Test
- ② In Vehicle Test
- 3 Review
- ④ Language
- 5 Backlight
- <sup>(6)</sup> Version

### How to use:

### 1. CONNECTION

Connect the red test clamp with battery anode and the black one with cathode, the tester will power on automatically. Voltage battery below 7.0VDC can't be tested properly, then press ENTER key to continue.

### 2. OUT OF VEHICLE TEST





### 3. IN VEHICLE TEST



# Notes:1). If you only want to check battery healthy, choose Out of vehicle test function 2). Cranking and Charging System Test, choose In vehicle test function

### 4. REVIEW

Choose Review and press ENTER, you can see 20 groups of data

DA	ТА	16
GOOD	D BAT	TERY
HEALTHY	91%	555A
CHARGE	98%	12.59V
INTERNAL	R	5.37mΩ
RATED	580A	ССА

### 5. LANGUAGE

English, French, German, Spanish, Italian, Portuguese, Russian

### Notes:1). Other languages can be customized

### 6. BACKLIGHT

Choose IN THE ROOM or OUTSIDE, the backlight can be adjusted automatically.

BACKL IGHT SET

IN THE ROOM

OUTSIDE

## After-sale warranty

1.One Year warranty

2. The product passed CE, RoHS certification with quality and safety assurance

3.Add: 55# Gangda Avenue, North Section, Modern Industrial Port, Pixian, Chengdu, China 4.website:www.lancol.com