



HDL-MDH0610A.4D High Performance Dimmer

# buspro

#### Datasheet

Issued: September 26, 2021 File Edition: V1.0.2



Figure 1. High Performance Dimmer




Figure 2. Dimensions - Front View





Figure 3. Dimensions - Side View



Overview

High Performance Dimmer (See Figure 1) is a dimmer based on MOSFET dimming technology. The dimmer has 6 output channels, which can drive high-power load. Manual buttons and status indicators are available for debugging device. With scene and sequence controller, the dimmer supports short-circuit protection and overheat protection. It is applicable to high performance dimming fields.

#### **Functions**

- 6CH 10A MOSFET trailing dimming outputs
- Manual bypass button and LED status indicator of each channel are available.
- Low Threshold, High Threshold, Maximum Threshold are all available for each channel. Built-in 4 dimming curves.
- With a scene controller, 6 separate zones can be set, 12 scenes can be set for each zone, and 6 sequences with 12-step scene can be set for Zone 1.
- The running scene can be set when the device starts. The specified security scene can be locked through an external switch signal, which is not subject to any channel control at this time.
- A variety of device operation information can be displayed via software, for example power information, temperature information, channel information, etc.
- Support short-circuit protection, overheat protection and grounding protection.
- Optional power supply of 24V DC, 120mA current to the HDL Buspro interface.
- HDL Buspro communication is adopted. Device's basic information, zone, scene, sequence and the device operation information can be displayed and edited.

#### **Important Notes**

- Buspro cable CAT5E or dedicated HDL Buspro cable.
- Buspro connection Series connection (hand-in-hand connection)
- Check connection Check cable connection after installation, separate high and low voltage power cable.
  Ensure the three phase AC power cable, neutral line and PE cable are connected correctly.
- Output channels The current of each channel should not exceed 10A, and the total output current should not exceed 60A.
- The recommended types of load are incandescent light, low-voltage halogen light, dimmable LED light, etc.
- The dimmer only supports trailing edge mode. It is not allowed to connect inductive loads.
- Make sure the working temperature of the dimmer does not exceed 45°C.
- The 24V output power interface should not exceed the rated current of 120mA.

### **Product Information**

Dimensions - See Figure 2 - 3

- 1. Bypass buttons and LED indicators
- Short press the buttons to switch the channels, long press the buttons to dim; The LED indicators shows the current status of the channels.
- 2. Power switches and connection ports: There are three phases of AC power: Phase A, Phase B, Phase C, Neutral line N

Phase A: It provides drive power to CH1, CH2, and also provide power to the weak electricity system.

Phase B: It provides drive power to CH3, CH4.

Phase C: It provides drive power to CH5, CH6.

- 3. Output channel switches and connection ports
  - There are 6 output channels: CH1-6. They can control the switch of channels and support overload protection.
- $4.\ \mbox{PE}$  connection: Connects to the housing of the device.
- 5. HDL Buspro interface
- The 24V DC power interface does not need to connect to other device, when it is no need to provide power to the Buspro device.
- 6. Switch signal input terminal of Security Scene
- 7. Programming button and module indicator: When the module works properly, the indicator flashes. Press the programming button for 3 seconds, the address of the module can be modified via HDL Buspro Setup Tool.
- 8. Wiring holes for AC power cable.

Wiring - See Figure 4




#### **Safety Precautions**

- The installation and testing for the product must be carried out by HDL Automation Co., Ltd. or its appointed service agencies. The electric construction shall comply with local laws and safety regulations.
- The device should be wall mounted. HDL will not be responsible for any consequence caused by the inexpert or faulty installation and wiring methods, which are not in accordance with the instructions contained in this operating instruction.
- Please do not privately disassemble or replace any parts of the product. Otherwise, it may cause mechanical fault, electric shock, fire or personal injuries.
- Please contact our after-sales departments or our designated service agencies for your maintenance service. Product failures caused by private disassembly are not subject to this warranty.
- It is not allowed to exceed the range.

#### **Package Contents**

HDL-MDH0610A.4D\*1 / Mounting support\*2 / Screw\*4 / Screw washer\*4 / Datasheet\*1












Figure 8

Figure 5 - 8. Installation

#### Technical support

E-mail: hdltickets@hdlautomation.com Website: https://www.hdlautomation.com

 ${\tt @Copyright\ by\ HDL\ Automation\ Co.,\ Ltd.\ All\ rights\ reserved}.$ Specifications subject to change without notice.

Technical Data		
Basic Parameters		
Input voltage	AC100~240V (50/60Hz)	
Power consumption without load	Less than 4W	
Output channel	6 channels	
Maximum output current of each channel	10A	
Maximum total output current of channels	60A	
Communication	HDL Buspro	
Connection	Three-phase four-wire system	
Dimming mode	Trailing edge	
Dimming curves	Linear, 1.5 exponent, 2.0 exponent, 3.0 exponent	
External Environment		
Working temperature	-5°C~45°C	
Working relative humidity	≤90%	
Storage temperature	-20°C~60°C	
Storage relative humidity	≤93%	
Specifications		
Dimensions	400x230x81(mm)	
Net weight	5.5kg	
Housing material	Iron	
Installation	Wall mounted (See Figure 5 - 8)	
Protection rating (Compliant with EN 60529)	IP20	
Approved		
CE		
RoHS		

RoHS

## **HDL Buspro Cable Guide**

HDL Buspro	HDL Buspro Cable	CAT5/CAT5E
DATA+	Yellow	Blue/Green
DATA-	White	Blue white/Green white
СОМ	Black	Brown white/Orange white
24V DC	Red	Brown/Orange

### Installation

Installation - See Figure 5 - 8

- Step 1. Fix two mounting supports on the wall with screws.
- Step 2. Pick up the device and align the gap in the back of the device with two wall mounting supports.
- Step 3. Hang the device on the wall hanging parts and fix it.